

Please do not attach your emblem until **AFTER** you have finished tightening your knock offs on your car.



Thank you for purchasing your new Tru=wire knock-off wheels from us. Our special emblems are being sent to you separate from the knock-offs that you have selected. We ask that you read and follow these simple instructions before installing your emblems on the knock-offs.

1) The knock-offs have a recessed area where the emblems will be installed. We recommend that the emblems **NOT** be attached to the knock-off **until after the knock-off has been tightened down on your adapter once installed on your car.**

2) After you have finished hammering the knock-off as tight and securely as you are able with your lead hammer on your car, you may then go forward and attach the emblem. The emblem itself has a 3M glue material on the backside. When you are ready to attach the emblem, simply peel off the 3M seal to expose the glue material.

3) Position the emblem exactly as you wish to have it displayed. We recommend showing the eagle positioned as shown with the Tru=wire script in a horizontal position. The tip of the eagle's wing should be at a 90 degree or straight-up position. Be careful that you install the emblem directly into the recessed area of the knock-off where it fits tightly. It is difficult to move the emblem once you have applied it.

4) After you have installed your emblem, it should look like the photo on the right. After you drive your car for 25 miles, re-tighten your knock offs being careful not to strike the emblem. The force involved with repeated blows to your knock-off can cause the black finish on the emblem to flake off. Please call us with any questions or comments.

Thank you.

